

E200P Installation Manual

(Version: V1.00)

The logo for ESTUN, consisting of the letters 'E', 'S', 'T', 'U', and 'N' stacked vertically in a large, bold, sans-serif font. The letters are white and set against a dark grey background. Above the letters, there are several diagonal white lines of varying lengths, creating a sense of motion or a stylized 'E' shape.

ESTUN AUTOMATION CO., LTD

— Total Solution Supplier



Version History

NO.	Date	Version	Description
1	2014-07-30	V1.00	Initial release.

Contents

Preface	1
Chapter 1 Specification	3
1.1 Display	3
1.2 Memory	3
1.3 Electrical Specification	3
Chapter 2 Installation and Wiring	5
2.1 Announcements before installation	5
2.2 Installation space and direction	5
2.3 Installation environment	5
2.4 Dimension	6
2.5 Installation layout and Interface.....	7
2.5.1 Layout of rear panel	7
2.5.2 Definition of power interface	7
2.5.3 Definition of input interface	7
2.5.4 Definition of output interface	8
2.5.5 Definition of encoder interface	8
2.5.6 Definition of communication interface	8
Chapter 3 Parameter Setting	9
3.1 Home Page	9
3.2 System Parameter	12
3.3 X-axis Parameter	13
3.4 Y-axis Parameter	15
3.5 YV Setting	16
3.6 Backup and Load	17
Chapter 4 Diagnose.....	18
4.1 Home Page	18
4.2 Input Diagnose.....	19
4.3 Output Diagnose	20
4.4 Keyboard Diagnose.....	21
4.5 FRAM Diagnose.....	22
4.6 ENC. Diagnose	23
4.7 LCD Diagnose.....	24
4.8 Factory Setting.....	25
Chapter 5 Commissioning	26
5.1 Preparation before commissioning	26
5.2 Procedure	26
5.2.1 Parameter setting.....	26
5.2.2 Manual movement.....	27
5.2.3 Counting	27
5.2.4 Retract	27
5.2.5 Teaching	27

Chapter 6 Maintenance	28
6.1 Instructions to maintenance	28
6.2 Routine inspection	28
6.3 Periodic inspection	29
Appendix A Wiring	31
Appendix B Parameter Description	32

Preface

Synopsis

This document guides the operator how to install, configure and maintenance the E200P press break numerical control device.

- **Chapter 1** describes the specification of the product.
- **Chapter 2** guides the user how to install and wire, and describes the ports.
- **Chapter 3** describes the operation of the **Parameters setting** page.
- **Chapter 4** describes the operation of the **Diagnose** page.
- **Chapter 5** guides the user how to commissioning the device.
- **Chapter 6** guides the user how to maintenance.

Intended Audience

This document is intended for the **authorized and properly trained persons**:

- **Device manufacturer:** In the device production process, the people who diagnose the device have the highest managing privileges.
- **System integrators:** usually refers to the technical personnel of machine tool manufacturers, who can configure the machine parameters to commissioning the system.

Attention

- Copy right is preserved by ESTUN. Do not add or delete part or all of the manual content without ESTUN's consent. Do not use part or all of manual content for the third party's design.
- E200P device provides complete software control and has no mechanical protection device for operator or the tool machine. Therefore, in case of malfunction, machine tool must provide protection device for operator and external part of the machine tool. ESTUN is not responsible for any direct or indirect losses caused by normal or abnormal operation of the device.
- ESTUN preserves the right to modifying this manual in the event of function adding or print error.
- E200P device has the light protection function, but only works on the **CLOSED** stage, it is unavailable on others stage.

Caution Sign

The following symbols with an adjoining safety advice or notice are used in this document. You have to read the safety advices carefully and adhere them strictly!

 WARNING
Risk of injury! If you do not adhere the safety advise adjoining this symbol, there is danger to life and health of individuals!

 CAUTION
Hazard to individuals! If you do not adhere the safety advice adjoining this symbol, there is obvious hazard to individuals!

 NOTE
Note or pointer. This symbol indicates information that contributes to better understanding.

Chapter 1 Specification

1.1 Display

LCD

Dimension of display window: 54.38mm*54.38mm

Dot matrix: 320*240

Status light

Green light indicates the system is running.

Red light indicates the system is stop.

1.2 Memory

Capable of storing 40 programs, each program includes 25 steps at most.

1.3 Electrical Specification

Power Supply

Parameter	Min.	Standard	Max.	Unit
Voltage	20	24	28.8	V
Voltage fluctuation			3.6	Vss
Input current	0.8	1	1.5	A
Watt	16	24	43	W
Starting current			1.5	A

INPUT

Power	24VDC±10%
Input current	20mA
Signal characteristic	<ul style="list-style-type: none"> High level: $V_H \leq 30V$ Low level: $V_L \leq 1.2V$
Effective level	High level

OUTPUT

Output type	Open collector
Output voltage	$\leq 30VDC$
Output current	$\leq 100mA$
Signal characteristic	<ul style="list-style-type: none"> High level: $V_H \leq 30V$ Low level: $V_L \leq 1.0V$
Effective level	Low level

Encoder

Support type	complementary type / Voltage type
Supply power	12VDC
Supply current	200mA
Frequency response	500KHz
Input phase	A, B, C
Output phase	A, B, C
Output voltage	<ul style="list-style-type: none"> • High level: $V_H \geq 80\%V_{CC}$ • Low level: $V_L \leq 0.3V$

Communication

Interface	CAN	RS485	RS232
Signal speed	1Mbps	115.2Kbps	115.2Kbps
Terminal resistance	External increase		-
BUS-ESD	16KV HBM	16KV HBM	15KV HBM
Mode	Half duplex		-

Transportation and Storage

Parameter	Description
Temperature	-20~55℃
Relative humidity	5~95% No condensation
Free fall ¹⁾	≤0.5m

1: With transport packaging

Chapter 2 Installation and Wiring

2.1 Announcements before installation

Before installation and wiring, please pay attention to the following matters:

- Power supply must be off during installation and wiring.
- Serious damage to the equipment may be caused by misconnection of power supply terminals, improper connection of in-out lines and output line short circuit. Therefore, before turning on the power supply, check the connection of input output grounding and power supply wire. .
- Grounding terminal of E200P digital control device must be grounded in correct way, with low impedance lower than 0.3Ω .
- Do not dismantle the device without authorization so as to avoid malfunction.
- Electrical components inside the digital device are very sensitive to static electricity, therefore do not put foreign matters or make them fall to the inside of digital control device or touch the control circuit.
- Please install E200P digital control device in safe region. Avoid high temperature, and direct sunlight, moisture and splash of oil drops or water.
- Do not use this device in place of high temperature, moisture condensation, dust, oil smoke, conductive dust, corrosive gas or flammable gas.

2.2 Installation space and direction

Generally, E200P press brake machine digital control device is embedded on control panel, keep a distance of 65mm from its neighboring components and damper (shell) on up and down, right and left, to facilitate operator install and maintain the device.

2.3 Installation environment

- Place free from water, vapor, dust or oily dust.
- Place free from flammable, explosive or corrosive gas.
- Place free from interference of strong electromagnetism or noise.
- Ambient temperature is between $0^{\circ}\text{C}\sim 40^{\circ}\text{C}$. When ambient temperature is over 40°C , please put it in well-ventilated place.
- Relative humidity is under 90% RH.

2.4 Dimension

The installation method is panel mounting. Installation dimension and drawings are shown in Figure 2-1.




Figure 2-1 Panel Installation Dimension

2.5 Installation layout and Interface

2.5.1 Layout of rear panel

Rear panel block diagram is shown in Figure 2-2, consisting of power port (POWER), input port (INPUT), output port (OUTPUT), encoder port (X, Y), and communication port (COMM).






Figure 2-2 Rear panel layout

2.5.2 Definition of power interface



Pin	1	2	3
Signal	+24V	GND	EARTH


2.5.3 Definition of input interface



Pin	Signal	Software Define
1	I1	Step
2	I2	Press
3	I3	PedalDn
4	I4	PedalUp
5	I5	Mode


Pin	Signal	Software Define
6	I6	Safeln
7	I7	MRDY
8	I8	-
9	COM	COM1

2.5.4 Definition of output interface




Pin	Signal	Software Define
1	O1	Y1
2	O2	Y2
3	O3	Y3
4	O4	Y4
5	O5	Y5
6	O6	EH
7	O7	ER
8	O8	-
9	COM	COM2

2.5.5 Definition of encoder interface



Pin	1	2	3	4	5	6	7	8, 9	Shell
Signal	GND	+12V	C	B	A	GND	+12V	NC	EARTH

2.5.6 Definition of communication interface



Pin	1	6	7	8	9	4	2	3	5	Shell
Signal	CANH	CANL	+3.3V	485A	485B	BOOT	TXD	RXD	GND	EARTH

Chapter 3 Parameter Setting

3.1 Home Page

Enter the **PARAMETER SET** page as follows:

Step 1 When the E200P device is electrified, wait a few seconds into the **SINGLE** page (Default page), as shown in Figure 3-1.

SINGLE	
X =	100.50 Y = 120.05
XP =	55.00 YP = 0.00
DX =	20.00 HT = 2.00
DLY =	2.00 PP = 150
CP =	100 OPN = 0.00
↗:DestPos Of Axis X Unit:mm	

Figure 3-1 The **SINGLE** page

Step 2 Press  two times to enter the **CONST** page, as shown in Figure 3-2.

CONST	
mm/inch:	0 0:mm 1:inch
中文/English:	1 0:中文 1:En.
Release Delay:	0.50 S
Hold Delay:	3.00 S
Retract Delay:	2.00 S
Version:	V1.00
↗:Unit of Length	

Figure 3-2 The **CONST** page

The description of the **CONST** parameters is as shown in Table 3-1.

Table 3-1 The description of the **CONST** parameters

Parameter	Default	Range	Unit	Description
mm/inch	0	0~1	-	<ul style="list-style-type: none"> 0: mm 1: inch
中文/English	0	0~1	-	<ul style="list-style-type: none"> 0: 中文 1: English

Parameter	Default	Range	Unit	Description
Release Delay	0.50		s	The delay time for the slide releasing the pressure after bending.
Hold Delay	0.00	0.00~99.99	s	The delay time for the slide holding the pressure when it is bending.
Retract Delay	0.00	0.00~99.99	s	The delay time for the back gauge will go to retract.
Version	-	-	-	The current software version number.

[Teach-in parameter]

Move the cursor to parameter **mm/inch** or **中文/English**, enter the password **1212**, and press



to enter the **TchIn PARA** page, as shown in Figure 3-3.



Figure 3-3 The **Teach-In** Parameters page

The description of the **TchIn PARA** parameters is as shown in Table 3-2.

Table 3-2 The description of the **Teach-In** parameters

Parameter	Default	Range	Unit	Description
X-tea. in	10.00	0~9999.999	mm/inch	When the teaching of X-axis is enabling, the operator assigns to the X-axis of a correct value, to represent the back gauge current position.
Y-tea. in	10.00	0~9999.999	mm/inch	When the teaching of Y-axis is enabling, the operator assigns to the Y-axis of a correct value, to represent the slider current position.

[Configure parameter]

Move the cursor to parameter **mm/inch** or **中文/English**, enter the password **36987**, and press



to enter the **CONFIG PARA.** page, as shown in Figure 3-3.




Figure 3-4 The CONFIG PARA. page

The description of the CONFIG PARA. parameters is as shown in Table 3-3.

Table 3-3 The description of the Teach-In parameters

Parameter	Default	Range	Unit	Description
YV5->NCRDY	0	0, 1	-	<ul style="list-style-type: none"> 0: Disable, the function of YV output is normal. 1: Enable, the function of YV output is changed to NCRDY output.
Jog Mode	0	0, 1	-	<ul style="list-style-type: none"> 0: Semi. 1: Jog

Step 3 Move the cursor to parameter **mm/inch** or **中文/English**, enter the password **14789**, and press  to enter the **PARAMETER SET** page, as shown in Figure 3-5.




Figure 3-5 The PARAMETER SET page

---End

3.2 System Parameter

On the **SYS PARA.** page, move the cursor to parameter **1.SYSTEM PARA** (or press the number key 1), and press  to enter the first page of the **SYS PARA.**, as shown in Figure 3-6.

SYS PARA.		1/2 PG
X-Digits:	2	Bit
Y-Digits:	2	Bit
X-Safe:	10.00	mm
Y-Safe:	5.00	mm
Step Delay:	0.00	S
Light En.:	0	0-Dis. 1-En.
Cont. Enable:	0	0-Dis. 1-En.
Open En.:	1	0-Dis. 1-En.
↗:Digits of axis X		

Figure 3-6 The first page of the **SYS PARA.**

[Note] If the parameter **OPEN En.** is set to 1, press  key to enter the second page of the **SYS PARA.**, and set the linear relationship between the Open distance and duration.

The description of the **SYS PARA.** parameters is as shown in Table 3-4.

Table 3-4 The description of the **SYS PARA.** parameters

Parameter	Default	Range	Unit	Description
X-Digits	2	0~3	-	The number of decimal places to display the X-axis position parameters.
Y-Digits	2	0~3	-	The number of decimal places to display the Y-axis position parameters.
X-Safe	10.00	0~9999.999	mm/inch	X-axis will maintain low speed in this range.
Y-Safe	10.00	0~9999.999	mm/inch	Y-axis will maintain low speed in this range.
Step Delay	0	0~99.99	s	The waiting time of the X-axis, that enters the next step of bending.
Light En.	0	0~1	-	<ul style="list-style-type: none"> • 0: Disable • 1: Enable
Cont. Enable	0	0~1	-	<ul style="list-style-type: none"> • 0: Disable • 1: Enable

Parameter	Default	Range	Unit	Description
Open En.	0	0~1	-	<ul style="list-style-type: none"> 0: Disable 1: Enable
OPEN DIST	-	0~9999.999	mm/inch	After bending, the distance of Y-axis's opening. [Note] This parameter is displayed when Open En. is set to 1.
TIME(s)	-	0~99.99	s	After bending, the duration of the Y-axis's opening. [Note] This parameter is displayed when Open En. is set to 1.

3.3 X-axis Parameter

On the **SYS PARA.** page, move the cursor to parameter **2.X AXIS PARA** (or press the number key 2), and press  to enter the first page of the **X PARA.**, as shown in Figure 3-7.




Figure 3-7 The first page of **X PARA.**

[Note] Press  or  to enter other page of **X PARA.**

The description of the **X PARA.** parameters is as shown in Table 3-5.

Table 3-5 The description of the **X PARA.** parameters

Parameter	Default	Range	Unit	Description
X-Enable	1	0~1	-	<ul style="list-style-type: none"> 0: Disable 1: Enable
X FactA	40	1~99999999	-	Multiplication factor of the X-axis, to as the pulse and millimeter conversion.
X FactB	1	1~99999999	-	Division factor of the X-axis, to as the pulse and millimeter conversion.

Parameter	Default	Range	Unit	Description
X-MotorDirection	0	0~1	-	<ul style="list-style-type: none"> • 0: CW • 1: CCW
X-Encoder Dir.	0	0~1	-	<ul style="list-style-type: none"> • 0: Decrement • 1: Increment
M-Min	5.00	0~9999.999	mm/inch	The minimum position of the X-axis.
M-Max	500.00	0~9999.999	mm/inch	The maximum position of the X-axis.
X-Teach. En.	1	0~1	-	<ul style="list-style-type: none"> • 0: Disable • 1: Enable
X-Ref. Pos.	500.00	0~9999.999	mm/inch	The position when X-axis finds the reference position.
X-Tolerance	0.05	0~99.999	mm/inch	Location tolerance. The system completes orientation at this range.
X-Overrun En.	0	0~1	-	<ul style="list-style-type: none"> • 0: Disable • 1: Enable
X-Over. Dis.	10.00	0~9999.999	mm/inch	Overrun distance. Effective in unilateral positioning.
X-Acc.SPM	1500	0~3000	SPM	The related parameters of the motor.
X-Aec.SPM	1500	0~3000	SPM	
Orientation	1500	0~1500	SPM	
M_Low Speed	200	0~3000	SPM	
Ref. Speed	200	0~3000	SPM	
Driven Mode	0	0~1	-	<ul style="list-style-type: none"> • 0: EDC • 1: ProNet

3.4 Y-axis Parameter

On the **SYS PARA.** page, move the cursor to parameter **3.Y AXIS PARA** (or press the number key 3), and press  to enter the first page of the **Y PARA.**, as shown in Figure 3-8.

Y PARA.		1/3 PG
Y-Enable:	0	0-Dis. 1-Enable
Y FactA:	40	
Y FactB:	1	
Y-MotorDirection:	1	0: CW 1: CCW
Y-Encoder Dir.:	0	0-Dec. 1-Inc.
Y-Max:	500.00	mm
Y-Min:	5.00	mm
		

Figure 3-8 The first page of **Y PARA.**

[Note] Press  or  to enter other pages of **Y PARA.**

The description of the **Y PARA.** parameters is as shown in Table 3-6.

Table 3-6 The description of the **Y PARA.** parameters

Parameter	Default	Range	Unit	Description
Y-Enable	1	0~1	-	<ul style="list-style-type: none"> 0: Disable 1: Enable
Y FactA	40	1~99999999	-	Multiplication factor of the Y-axis, to as the pulse and millimeter conversion.
Y FactB	1	1~99999999	-	Division factor of the Y-axis, to as the pulse and millimeter conversion.
Y-MotorDirection	0	0~1	-	<ul style="list-style-type: none"> 0: CW 1: CCW
Y-Encoder Dir.	0	0~1	-	<ul style="list-style-type: none"> 0: Decrement 1: Increment
Y-Min	5.00	0~9999.999	mm/inch	The minimum position of the Y-axis.
Y-Max	500.00	0~9999.999	mm/inch	The maximum position of the Y-axis.
Y-Teach. En.	1	0~1	-	<ul style="list-style-type: none"> 0: Disable 1: Enable
Y-Ref.Pos.	500.00	0~9999.999	mm/inch	The position when Y-axis finds the reference position.
Y-Tolerance	0.02	0~99.999	mm/inch	Location tolerance. The system completes orientation at this range.

Parameter	Default	Range	Unit	Description
Y-Overrun En.	0	0~1	-	<ul style="list-style-type: none"> 0: Disable 1: Enable
Y-Over. Dis	10.00	0~9999.999	mm/inch	Overrun distance. Effective in unilateral positioning.
Y-Acc. SPM	1500	0~3000	SPM	The related parameters of the motor.
Y-Dec. SPM	1500	0~3000	SPM	
Orientation	1000	0~1500	SPM	
M_Low Speed	200	0~500	SPM	
Ref. Speed	200	0~3000	SPM	
Driven Mode	0	0~1	-	<ul style="list-style-type: none"> 0: EDC 1: ProNet

3.5 YV Setting

On the **SYS PARA.** page, move the cursor to parameter **4.YV SETTING** (or press the number key 4), and press  to enter the **YV MONITOR** page, as shown in Figure 3-9.

[Operation Guide]: Press  and  to select the YV need to be configured, and press number key to enter the value (the number key 1 to 5 respectively corresponding **YV1** to **YV5**), and then press  to confirm.




Figure 3-9 The **YVSet** page

[Note]: To clear the configuration of the YV, press number key **0**.

3.6 Backup and Load

NOTE

The **BACKUP/LOAD** page does not make processing to the program parameters, such as **SINGLE** parameters, **MUTIL-STEP** parameters.

- **BACKUP**: store the current parameter settings.
- **LOAD**: recovery the current parameter settings to the last backup.

On the **SYS PARA.** page, move the cursor to parameter **5.BACKUP/LOAD** (or press the number key **5**), and press  to enter the **BACKUP/LOAD** page, as shown in Figure 3-10.

[Operation Guide]:

- Move the cursor to parameter **1.PARA BACKUP**, and long press  to start backup operation, until the page tips **Backup Done**.
- Move the cursor to parameter **2.PARA LOAD**, and long press  to start backup operation, until the page tips **Load Done**.
- Press  to return to the **PARAMETER SET** page.




Figure 3-10 The **BACKUP/LOAD** page

Chapter 4 Diagnose

4.1 Home Page

Enter the **DIAGNOSE** page as follows:

- Step 1** When the E200P device is electrified, wait a few seconds into the **SINGLE** page (Default page).
- Step 2** Press  two times to enter the **CONST** page.
- Step 3** Move the cursor to parameter **mm/inch** or **中文/English**, enter the password **5656**, and press  to enter the **PARAMETER SET** page, as shown in Figure 4-1.




Figure 4-1 The **DIAGNOSE** page

---End

4.2 Input Diagnose

On the **DIAGNOSE** page, move the cursor to parameter **1.IN DIAG.** (or press the number key 1), and press  to enter the **IN DIAG.** page, as shown in Figure 4-2.

[Operation Guide]:

- Switching high level to the corresponding relay, the device will detect the input signal, and the background color of the corresponding port icon on the page will change, that this input port is normal.
- Press  to return to the **DIAGNOSE** page.




Figure 4-2 The **IN DIAG.** page

4.3 Output Diagnose

On the **DIAGNOSE** page, move the cursor to parameter **2.OUT DIAG.** (or press the number key 2), and press  to enter the **OUT DIAG.** page, as shown in Figure 4-3.

[Operation Guide]:

- Move the cursor to any icon of the port, and press  to switch the level. If the background color of the corresponding port icon on the page changes, and the corresponding relay turns, that this output port is normal.
- Press  to return to the **DIAGNOSE** page.




Figure 4-3 The **OUT DIAG.** page

4.4 Keyboard Diagnose

On the **DIAGNOSE** page, move the cursor to parameter **3.KEY DIAG.** (or press the number key **3**), and press  to enter the **KEY DIAG.** page, as shown in Figure 4-4.

[Operation Guide]:

- Press any key on the operation board, and check the key name feedback on the page whether is correct.
- Press  to return to the **DIAGNOSE** page.




Figure 4-4 The **KEY DIAG.** page

4.5 FRAM Diagnose

On the **DIAGNOSE** page, move the cursor to parameter **4.KEY DIAG.** (or press the number key 4), and press  to enter the **KEY DIAG.** page, as shown in Figure 4-5.

[Operation Guide]:

- Press  to start diagnosing. If the FRAM is normal, the page will tip **The result is: OK.**
- Press  to return to the **DIAGNOSE** page.




Figure 4-5 The **FRAM DIAG.** page

4.6 ENC. Diagnose

On the **DIAGNOSE** page, move the cursor to parameter **5.ENC. DIAG.** (or press the number key **5**), and press  to enter the **ENC. DIAG.** page, as shown in Figure 4-6.

[Operation Guide]:

- Rotating the Encoder, the corresponding C pulse width will change between 0 and 1, and the value of Vn (n is the port number of the encoder) changes, that the encoder port is normal.
- Press  to return to the **DIAGNOSE** page.




Figure 4-6 The **ENC. DIAG** page

4.7 LCD Diagnose

On the **DIAGNOSE** page, move the cursor to parameter **6.LCD DIAG.** (or press the number key **6**), and press  to enter the **LCD DIAG.** page, as shown in Figure 4-7.

[Operation Guide]:

LCD diagnose is mainly used for checking the screen whether there is bright or dark spots.

- Press  to start diagnosing, the page switch to the monochrome screens, please check whether there is bright or dark spots.
- Press  to return to the **DIAGNOSE** page.



Figure 4-7 The **LCD DIAG.** page

4.8 Factory Setting

NOTE

The **RESUME** page does not make processing to the program parameters, such as **SINGLE** parameters, **MUTIL-STEP** parameters.

On the **DIAGNOSE** page, move the cursor to parameter **7.RESTORE**. (or press the number key 7), and press  to enter the **RESUME** page, as shown in Figure 4-8.

[Operation Guide]:

- Press  to factory setting, until the page tips “恢复完成, 请重启!” and then restart the device.
- Press  to return to the **DIAGNOSE** page.




Figure 4-8 The **RESUME** page

Chapter 5 Commissioning



When commissioning starts, watch carefully whether motor runs normally or mechanical impacts may be caused. If necessary, cut down motor power immediately to avoid accident.

5.1 Preparation before commissioning

- Check the power line, ground wire, input/output signal wire and encoder plug for reliable and accurate connection.
- Check whether output voltage of 24V switch power is normal or not.
- Check power supply and ground wire before power on the system.
- Enter **Diagnose** page, check system's input signal. When there is input signal, the corresponding input indication is filled; otherwise, input signal is not connected.
- Enter **Diagnose** page, check system's output signal. When there is output signal, the corresponding output indication is filled. If machine tool fails to operate normally, check electrical parts of the machine tool.

5.2 Procedure

5.2.1 Parameter setting

- 1 When the E200P device is electrified, wait a few seconds into the **SINGLE** page (Default page).
- 2 Press  two times to enter the **CONST** page.
- 3 Move the cursor to parameter **mm/inch** or **中文/English**, enter the password **14789**, and press  to enter the **PARAMETER SET** page.
- 4 Move the cursor to parameter **2.X AXIS PARA** (or press the number key **2**), and press  to enter the first page of the **X PARA**.
- 5 Set the following parameter on the **X PARA**. page:
 - X-Enable: 1
 - X FactA: 40
 - X FactB: 1
 - X-Encoder Dir.: 1
 - X-Min: 10.00
 - X-Max: 500.00 (this value is determined by gauge length)
 - X-Teach. En: 1
 - X-Ref. Pos: 10.00
 - X-Overrun. En.: 1
 - X-Over. Dis.: 5.00
- 6 Press  to return to the **PARAMETER SET** page.

- 7 Move the cursor to parameter **3.Y AXIS PARA** (or press the number key **3**), and press  to enter the first page of the **Y PARA**.
- 8 Set the parameter on the **Y PARA**. page, the setting is the same with X-axis.

5.2.2 Manual movement

- 1 When the E200P device is electrified, wait a few seconds into the **SINGLE** page (Default page).
- 2 Press  or  to enter the **MANUAL** page.
- 3 Adjust the X-axis and Y-axis manually.
 - Press and hold , watch the gauge whether move to the maximum position slowly, if not, please enter the **X PARA**. page, and set the parameter **X-MotorDirection** to **1**.
 - Watch the encoder counting direction whether is correct. If it is incorrect, please enter the **X PARA**. page, and set the parameter **X-Encoder Dir.** to **0**.
 - Press  and  simultaneity, and watch the gauge whether move to the minimum position fast.
 - Confirm that the front and rear limit are effective.

5.2.3 Counting

Edit multistep program on programming page (setting number of work piece is over 1, single step is excluded), press , and depress pedal to dry running when X, Y axle are in position (note Y axle position and pressure), observe whether counting has increased; if no change occurs, check whether **I1** signal wire (**Step**) is reliably connected to the system.

5.2.4 Retract

Edit single-step program on programming page (yield parameter is 5mm), press  and depress pedal to dry running when X, Y axle are in position (note Y axle position and pressure).observe whether there is yield and yield sequence is correct. If error, check whether **I2** signal wire (**Press**) is reliably connected to the system, and whether yield distance (Dx value) set is correct and reasonable.

5.2.5 Teaching

When the above procedures are finished, roughly correct actual position of X and Y axle by teach function. Edit single step program to carry out actual processing, measure dimension of the processed work piece, then correct scale error by teach function.

Chapter 6 Maintenance

6.1 Instructions to maintenance

In order to use this system safely and properly, follow the instructions.

- When power is on or system operates normally, do not open cover plate or panel as it may damage the components.
- Wiring and inspection shall be done by professionals.
- Don't touch IC pin or contact of joint.
- Do not place system on metal product that may cause power leakage, or on wood, plastic or vinyl product which has static electricity.
- If self-diagnosis error occurs to the system, determine details in accordance with warning instructions and eliminate causes to error. Ensure safety. Rerun when warning is removed. (Refer to Appendix 1 Warning list and instructions)
- Before operation, determine and adjust program and each parameter.
- Do not add voltage values excluded in operating manual on any binding post. Otherwise damage or breakage may be caused.
- Do not misconnect terminals. Otherwise damage or breakage may be caused.
- Do not mistake polarity (+/-) . Otherwise damage or breakage may be caused.
- Control line and communication cable shall not be together with or close to principal line and power harness. Their distance between each other shall be over 100mm during installation.

6.2 Routine inspection

For routine inspection, please refer to Table 6-1.

Table 6-1 Routine inspection

No.	Inspection item	Standard content	Standard specification	Treatment
1	Basic installation status of the system	Check set screw for loosening, and check seal for drop.	Be installed properly.	Fasten screw.
2	IO port connection status	Check IO port connection for loosening	Correct wiring.	Correct wiring.
3	Connection status	Check terminal screw for loosening	Screw is not loose	Fastening terminal screw.
4	LED display status	Check whether LED display is correct.	LED (green) indicate system running, LED (red) indicate system stop.	-

6.3 Periodic inspection


Items which require once or twice inspection every 6 months or 1 year are listed below. In case of equipment removal or reconstruction, or any changes to wiring, inspection is also required. Please refer to Table 6-2 for inspection content.

Table 6-2 Periodic inspection content

No.	Inspection item		Standard content	Standard specification	Treatment
1	Surrounding environment	Ambient temperature	Measure by thermometer, humid meter, and measure whether corrosive gas exists.	0~40℃	-
		Ambient humidity		5~95%RH	
		Air		No corrosive gas	
2	Voltage		Voltage among terminals 24V DC	20~29V DC	Change power supply
3	Install	Tension, mobility	Mobile module	Module must be installed securely.	Secure the screw. If CPU and I/O module loses, fasten them by screws.
		Dust and foreign matter attachment	Visual observation	No dust or foreign matter is allowed.	Remove and clean.
4	Connection status	Tightness of terminal screw	Rotate by screwdriver	No loosening	Screw
		Whether compression type terminal is close	Visual inspection	Compression type terminal must be fixed between proper intervals.	Adjust

No.	Inspection item		Standard content	Standard specification	Treatment
		Tightness of joint	Visual inspection	No loosening	Tighten screw
5	Relay		Multimeter, visual inspection	Whether contact pull-in is normal. Coil resistance	Replace relay.

Appendix A Wiring



Appendix B Parameter Description

Parameter	Default	Range	Unit	Description
CONST				
mm/inch	0	0~1	-	<ul style="list-style-type: none"> • 0: mm • 1: inch
中文/English	0	0~1	-	<ul style="list-style-type: none"> • 0: 中文 • 1: English
Release Delay	0.50		s	The delay time for the slide releasing the pressure after bending.
Hold Delay	0.00	0.00~99.99	s	The delay time for the slide holding the pressure when it is bending.
Retract Delay	0.00	0.00~99.99	s	The delay time for the back gauge will go to retract.
Version	-	-	-	The current software version number.
TchIn PARA				
X-tea. in	10.00	0~9999.999	mm/inch	When the teaching of X-axis is enabling, the operator assigns to the X-axis of a correct value, to represent the backgauge current position.
Y-tea. in	10.00	0~9999.999	mm/inch	When the teaching of Y-axis is enabling, the operator assigns to the Y-axis of a correct value, to represent the slider current position.
CONFIG PARA.				
YV5->NCRDY	0	0, 1	-	<ul style="list-style-type: none"> • 0: Disable, the function of YV output is normal. • 1: Enable, the function of YV output is changed to NCRDY output.
Jog Mode	0	0, 1	-	<ul style="list-style-type: none"> • 0: Semi. • 1: Jog

Parameter	Default	Range	Unit	Description
SYS PARA.				
X-Digits	2	0~3	-	The number of decimal places to display the X-axis position parameters.
Y-Digits	2	0~3	-	The number of decimal places to display the Y-axis position parameters.
X-Safe	10.00	0~9999.999	mm/inch	X-axis will maintain low speed in this range.
Y-Safe	10.00	0~9999.999	mm/inch	Y-axis will maintain low speed in this range.
Step Delay	0	0~99.99	s	The waiting time of the X-axis, that enters the next step of bending.
Light En.	0	0~1	-	<ul style="list-style-type: none"> ● 0: Disable ● 1: Enable
Cont. Enable	0	0~1	-	<ul style="list-style-type: none"> ● 0: Disable ● 1: Enable
Open En.	0	0~1	-	<ul style="list-style-type: none"> ● 0: Disable ● 1: Enable
OPEN DIST	-	0~9999.999	mm/inch	After bending, the distance of Y-axis's opening. [Note] This parameter is displayed when Open En. is set to 1 .
TIME(s)	-	0~99.99	s	After bending, the duration of the Y-axis's opening. [Note] This parameter is displayed when Open En. is set to 1 .
X PARA.				
X-Enable	1	0~1	-	<ul style="list-style-type: none"> ● 0: Disable ● 1: Enable
X FactA	40	1~99999999	-	Multiplication factor of the X-axis, to as the pulse and millimeter conversion.
X FactB	1	0~99999999	-	Division factor of the X-axis, to as the pulse and millimeter conversion.

Parameter	Default	Range	Unit	Description
X-MotorDirection	0	0~1	-	<ul style="list-style-type: none"> 0: CW 1: CCW
X-Encoder Dir.	0	0~1	-	<ul style="list-style-type: none"> 0: Decrement 1: Increment
X-Min	5.00	0~9999.999	mm/inch	The minimum position of the X-axis.
X-Max	500.00	0~9999.999	mm/inch	The maximum position of the X-axis.
X-Teach. En.	1	0~1	-	<ul style="list-style-type: none"> 0: Disable 1: Enable
X-Ref. Pos.	500.00	0~9999.999	mm/inch	The position when X-axis finds the reference position.
X-Tolerance	0.05	0~99.999	mm/inch	Location tolerance. The system completes orientation at this range.
X-Overrun En.	0	0~1	-	<ul style="list-style-type: none"> 0: Disable 1: Enable
X-Over. Dis.	10.00	0~9999.999	mm/inch	Overrun distance. Effective in unilateral positioning.
X-Acc.SPM	1500	0~3000	SPM	The related parameters of the motor.
X-Aec.SPM	1500	0~3000	SPM	
Orientation	1500	0~1500	SPM	
M_Low Speed	200	0~3000	SPM	
Ref. Speed	200	0~3000	SPM	
Driven Mode	0	0~1	-	<ul style="list-style-type: none"> 0: EDC 1: ProNet
Y PARA.				
Y-Enable	1	0~1	-	<ul style="list-style-type: none"> 0: Disable 1: Enable
Y FactA	40	1~99999999	-	Multiplication factor of the Y-axis, to as the pulse and millimeter conversion.
Y FactB	1	1~99999999	-	Division factor of the Y-axis, to as the pulse and millimeter conversion.
Y-MotorDirection	0	0~1	-	<ul style="list-style-type: none"> 0: CW 1: CCW
Y-Encoder Dir.	0	0~1	-	<ul style="list-style-type: none"> 0: Decrement 1: Increment

Parameter	Default	Range	Unit	Description
Y-Min	5.00	0~9999.999	mm/inch	The minimum position of the Y-axis.
Y-Max	500.00	0~9999.999	mm/inch	The maximum position of the Y-axis.
Y-Teach. En.	1	0~1	-	<ul style="list-style-type: none"> 0: Disable 1: Enable
Y-Ref.Pos.	500.00	0~9999.999	mm/inch	The position when Y-axis finds the reference position.
Y-Tolerance	0.05	0~99.999	mm/inch	Location tolerance. The system completes orientation at this range.
Y-Overrun En.	0	0~1	-	<ul style="list-style-type: none"> 0: Disable 1: Enable
Y-Over. Dis	10.00	0~9999.999	mm/inch	Overrun distance. Effective in unilateral positioning.
Y-Acc. SPM	1500	0~3000	SPM	The related parameters of the motor.
Y-Dec. SPM	1500	0~3000	SPM	
Orientation	1500	0~1500	SPM	
M_Low Speed	200	0~3000	SPM	
Ref. Speed	200	0~3000	SPM	
Driven Mode	0	0~1	-	<ul style="list-style-type: none"> 0: EDC 1: ProNet
SINGLE				
XP	0.00	0~9999.999	mm/inch	Program position of X axle.
YP	0.00	0~9999.999	mm/inch	Program position of Y axle.
DX	0.00	0~9999.999	mm/inch	Retract distance of X axle.
HT	0.00	0~99.99	s	The time between concession signal valid and end hold time output.
DLY	0.00	0~99.99	s	In case of single step, delay time for X-axis retracting.
PP	0	0~9999	-	The number of processing workpiece in this program.
CP	0	0~9999	-	<ul style="list-style-type: none"> PP=0: this value is the current work piece. PP>0: this value is the remain work piece.
OPN	0.00	0~999.999	mm/inch	After bending, the distance of the Y-axis opening.

Parameter	Default	Range	Unit	Description
PROGRAM				
ST	1	0~25	-	The total number of steps in this program.
PP	0	0~99999	-	The number of processing workpiece in this program.
CP	0	0~99999	-	<ul style="list-style-type: none"> • PP=0: this value is the current work piece. • PP>0: this value is the remain work piece.
DLY	0.00	0~99.99	s	In case of single step, delay time for X-axe retracting.
HT	0.00	0~99.99	s	The time between concession signal valid and end hold time output.
STEP				
XP	0.00	0~9999.999	mm/inch	Program position of X-axis.
YP	0.00	0~9999.999	mm/inch	Program position of Y-axis.
DX	0.00	0~9999.999	mm/inch	Retract distance of X axle.
OPEN DIST	0.00	0~999.999	mm/inch	After bending, the distance of the Y-axis opening.
Repeat Times	1	1~99	-	The repeat times in this step.



ESTUN AUTOMATION CO., LTD

Add: 155 Jiangjun Road, Jiangning Development Zone,
Nanjing 211106, P.R.China

TEL: 025-52785866

FAX: 025-52785992

WEB: www.estun.com

Email: info@estun.com



www.estun.com

ESTUN